





Assembly Instructions  
**MODEL NO. : 177523-1**  
 DESK MATE RH

1	2	3	4
 Cam lock 15pcs	 Klix Cam 15pcs	 Cam Cover 15pcs	 Dowel 14pcs



**IMPORTANT:**

FUNCTION OF KLIX CAM



1/4 RIGHT TURN FOR LOCKING

Make Sure The Arrow Is Pointing Upwards Before Inserting Into The Panel's Hole

**IMPORTANT NOTE:**

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children