









Assembly Instructions

MODEL NO.:177513-1


HUTCH 1200W

1	 Cam Lock 20pcs	2	 Klix Cam 20pcs	3	 Cam Cover 20pcs	4	 Dowel 20pcs	5	 Shelf supporter 16 pcs	6	 6hole L-Bracket 4pcs	7	 Screw#4*16mm 24pcs
---	---	---	--	---	---	---	---	---	---	---	--	---	--



STEP1




STEP2



STEP3



COMPLETED ASSEMBLY




- IMPORTANT NOTE:**
- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
 - Check to be sure that you have all parts and hardware.
 - Remove all wrapping materials, including staples & packing straps before you start to assemble.
 - Don't tighten all screws/bolts until all completely assembled.
 - Keep all hardware parts out of reach of children



IMPORTANT:

FUNCTION OF KLIX CAM



1/4 RIGHT TURN FOR LOCKING

Make Sure The Arrow Is Pointing Upwards Before Inserting Into The Panel's Hole