

We recommend that this Bookcase is fixed to the wall to prevent tipping. Please consult your local Hardware store to recommend the best fixture suitable for your wall application

OB225 1800 Bookcase



Please follow these Assembly Instructions.

This will save you time, make assembly easier and prevent possible damage to your new Bookcase. Assistance may be required for some assembly procedures. Correct assembly is your responsibility.

We recommend that the unit is assembled on a soft surface such as carpet.

Please record your serial number in the space provided below and retain this manual for future reference.

Serial No



For warranty registration and information please go to
www.jasperj.co.nz




Unpack & Identify Parts



ATTENTION:


The maximum recommended loading for each Shelf is 24.0 kg with a deflection not exceeding 4mm



AOB2250B7 carton contents

<u>Part Description</u>	<u>Quantity</u>	<u>Part Number</u>
		Beech
Top	1	IOB2250B701
Base	1	IOB2250B702
Left side	1	IOB2250B703
Right side	1	IOB2250B704
Fixed shelf	1	IOB2250B705
Adjustable shelves	3	IOB2250B706
Backs	2	IOB2250B707
Joining strip	1	IOB2250B708
Hardware pack	1	IOB2250HPA0

Tool required



Phillips No.2 Screwdriver or a
Phillips No.2 Pozi drive

Customer Service

0800 450 314

To request spare parts, please provide the details in step one - six.

1. Model number of unit purchased
2. Proof of purchase
3. Description of missing part
4. Part number of missing part
5. Quantity of missing part
6. Serial number of the unit



Post request to.

OR

Scan and take photos
of any damaged parts



JasperJ helpdesk
P.O. Box 47130,
Ponsonby
Auckland 1144

customerservice@jasperj.co.nz



Before requesting spare parts, please ensure that you have checked your packaging and used the correct hardware at each step.




JASPER J

Hardware contents: IOB2250HPA0



Connector Rod
IDG0044 x 8




Dowel
IDG0045 x 8




Screw
P860250 x 4




Screw
IDG0098 x 4




Cam
IDG0041 x 8



Pin Support
P840002 x 4




Shelf Pin
P840048 x 12



Pin Glide
IDG0042 x 4


Step 1 Prepare Side panels



x 8




x 4



Left side

groove on back edge

bottom edge



x 4

Right side

bottom edge


Step 2 Prepare Top & Base



HINT

Cam fitting detail

When inserting Cam, ensure arrowhead on Cam points to the edge of hole on panel




Arrowhead





x 8




x 8



groove in
Top panel




Step 3



Turn Cams clockwise to tighten.





CAUTION: Unit does not have structural strength until the Backs and Right side panel are fitted.






Step 4 Prepare & fit Backs

 Assistance may be required for this step.




Assistance may be required to help fit the Back to the Unit.
Slide the Back down inside the groove on the Top panel and locate it inside the groove on the Side panel.

Step 5 Fit & secure Right side, Backs & Pin glides



Fit & secure the Right side panel. Secure Backs with Screws into the back edge of the Base panel. Fit Pin glides approximately 20 - 30mm in from the edges

Step 6 Fit Shelf supports & Shelves




x 12



ATTENTION:

The maximum recommended loading for each Shelf is 24.0 kg with a deflection not exceeding 4mm



CAUTION: We recommend that all contents stored in or on this item of furniture be removed before shifting it. The Manufacturer will not be held liable for damage caused when furniture is shifted without first removing its contents. If the furniture is shifted we recommend that it is lifted not dragged.