


Workspace Henley Chair



INSTRUCTION MANUAL

Maximum weight for this product is 120kgs

Assembly Details

10 MIN APPROXIMATE ASSEMBLY	1 PERSON ASSEMBLY	FLOOR AREA 1. 5Mx1. 5M REQUIRED ASSEMBLY SPACE
allen key		

Tips before you start


- 1. Please check that all parts are present before you start the assembly of your furniture.
- 2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
- 3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
- 4. We recommend that, where possible, all items are assembled near to the area in which
- 5. they will be placed in use, to avoid moving the product unnecessarily once assembled.
- 6. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- 7. During assembly please take care not to over-tighten any fittings, as this may damage the product. Do not use power tools.
- 8. Always place the product on a flat, steady and stable surface.
- 9. Do not stand on the product. Do not use the product as a stepladder.
- 10. This product is intended for indoor, household use only as it is a non-industrial product.
- 11. Please use caution and care when lifting the product to avoid personal injury and/or product damage.

Care and maintenance


- ✓ Please periodically check all fittings and re-tighten as necessary.
- ✓ To clean your item, please use a damp cloth and wipe clean.
- ✓ Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- ✓ Please do not place hot items (eg. hot drinks) directly on to the surface.
- ✓ Please do not drag and pull your furniture.

Part Name

HARDOARE LIST




PARTS LIST




Assembly


STEP1



STEP2



STEP3



STEP4







Warranty

We pride ourselves on producing a range of quality home appliances that are both packed with features and completely reliable. We are so confident in our products, we back them up with a 2 -year warranty.

Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274
This Product is covered by 2 -year warranty when accompanied by proof of purchase.