




®

WORKSPACE GAMING CHAIR





INSTRUCTION MANUAL

The Maximum Weight for this product is 120 kgs

AFTER SALES SUPPORT

 (NZ) 0800 422 274

Assembly Details

<p>10 MIN</p> <p>APPROXIMATE ASSEMBLY</p>	 <p>2 Persons Assembly</p>	<p>Floor Area 2m x 2m</p>  <p>REQUIRED ASSEMBLY SPACE</p>
 <p>allen key</p>		

Tips before you start

- 1 For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage
- 2 Please check that all parts are present before you start the assembly of your furniture.
- 3 For ease and speed of assembly, we recommend that you identify all the parts required for each step before commencing with assembly.
- 4 For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
- 5 We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily.
- 6 During assembly please take care not to over-tighten hardware, as this may damage the product. Do not use power tools.
- 7 Always place the product on a steady and stable surface.
- 8 Do not stand on the product. Do not use the product as a stepladder.
- 9 This product is intended for indoor, household use only as it is a non-industrial product.
- 10 Please use caution and care when lifting the product to avoid personal injury and/or product damage.


Care and maintenance

- ✓ Please periodically check all things and re-tighten as necessary.
- ✓ To clean your item, please use a damp cloth and wipe clean.
- ✓ Never allow any kind of liquid to remain on your furniture.
- ✓ Absorption can cause wood to warp or finishes to de-laminate.
- ✓ Please do not place hot items (eg. Hot drinks) directly on to the surface.
- ✓ Please do not drag and pull your furniture.

Part Name


				
Ax14	Bx2	Cx4	Dx1xPC(L&R)	Ex1

PARTS LIST


		
1 5xPC	2 1xPC	3 1xPC
		
4 1xPC	5 1xPC	6 1xPC
		
7 1xPC	8 1xPC (L&R)	9 2xPC

Assembly


STEP1




STEP2




STEP3




STEP4



STEP5



STEP6





WORKSPACE®

Warranty

We pride ourselves on producing a range of quality products that are both packed with features and completely reliable. We are so confident in our products, we back them up with a two year warranty. Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274
This product is covered by two year warranty when accompanied by proof of purchase.