


Ergo Plus Meshback Chair



INSTRUCTION MANUAL




The Maximum Weight for this product is 120 kgs

AFTER SALES SUPPORT



(NZ) 0800 222 246

Assembly Details

<div>10 MIN</div> <div>APPROXIMATE ASSEMBLY</div>	<div>1 PERSON ASSEMBLY</div> <div></div>	<div>FLOOR AREA 1.5Mx1.5M</div> <div></div> <div>REQUIRED ASSEMBLY SPACE</div>
<div></div> <div>allen key</div>		

Tips before you start

- 1 For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage
- 2 Please check that all parts are present before you start the assembly of your furniture.
- 3 For ease and speed of assembly, we recommend that you identify all the parts required for each step before commencing with assembly.
- 4 For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
- 5 We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily.
- 6 During assembly please take care not to over-tighten hardware, as this may damage the product. Do not use power tools.
- 7 Always place the product on a steady and stable surface.
- 8 Do not stand on the product. Do not use the product as a stepladder.
- 9 This product is intended for indoor, household use only as it is a non-industrial product.
- 10 Please use caution and care when lifting the product to avoid personal injury and/or product damage.


Care and maintenance
















- ✓ Please periodically check all things and re-tighten as necessary.
- ✓ Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.
- ✓ The castors should be kept clear of threads or other objects that would inhibit their movement
- ✓ Vacuum regularly. Protect from direct sunlight.
- ✓ Please do not place hot items (eg. Hot drinks) directly on to the surface.
- ✓ Please do not drag and pull your furniture.

Seating posture

- ✓ We recommend computer users adopt an open-angle sitting position with knees slightly lower than hips.
- ✓ Always sit near the back of your seat.
- ✓ Adjust your backrest angle and seat height to a position that allows you to sit close to your workstation.
- ✓ Your feet should be flat on the floor or on a footrest. There should be no pressure under your thighs.


Part Name






A  5PCS	B  1PC	C  1PC
D  1PC	E  1PC	F  1PC
G  1PC	H  2PCS	I  1PC
J M6×35mm  3PCS	K M8  3PCS	L M8*22*1.5mm  3PCS
M M6*15*1mm  6PCS	N M6×40mm  6PCS	O M5  1PC


Assembly

1.




N M6×40mm  6 PCS	M M6*15*1mm  2 PC	O M5  1 PC
--	---	--





2.




Assembly

3.




J	M6x35mm	K	M8	L	M8x22x1.5mm	O	M5
							
	3 PCS		3 PCS		3 PC		1 PC

4.



Assembly

5.



6.





WORKSPACE[®]

Warranty

We pride ourselves on producing a range of quality products that are both packed with features and completely reliable. We are so confident in our products, we back them up with a two year warranty. Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 222 246
This product is covered by two year warranty
when accompanied by proof of purchase.

AFTER SALES SUPPORT



NZ 0800 222 246