




COMMERCIAL DESK 1500



INSTRUCTION MANUAL

The Maximum Weight this product can hold up to 50 kgs

AFTER SALES SUPPORT


 (NZ) 0800 422 274

1

Assembly Details

0.5 hr

APPROXIMATE ASSEMBLY TIME






2 PERSONS OF ASSEMBLY

**FLOOR AREA
2 M X 1.5M**



REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS



AFTER SALES SUPPORT

 **NZ** 0800 422 274

Tips before you start


1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
4. We recommend that, where possible, all items are assembled near to the area in which
5. they will be placed in use, to avoid moving the product unnecessarily once assembled.
6. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
7. During assembly please take care not to over-tighten any fittings, as this may damage the product. Do not use power tools.
8. Always place the product on a flat, steady and stable surface.
9. Do not stand on the product. Do not use the product as a stepladder.
10. This product is intended for indoor, household use only as it is a non-industrial product.
11. Please use caution and care when lifting the product to avoid personal injury and/or product damage.

Care and maintenance


- ✓ Please periodically check all fittings and re-tighten as necessary.
- ✓ To clean your item, please use a damp cloth and wipe clean.
- ✓ Never allow any kind of liquid to remain on your furniture.
Absorption can cause wood to warp or finishes to de-laminate.
- ✓ Please do not place hot items (eg. hot drinks) directly on to the surface.
- ✓ Please do not drag and pull your furniture.

Part List

NO.	PART LIST	QTY	NO.	PART LIST	QTY
(A)	RIGHT SIDE PANEL	1	(C)	TOP PANEL	1
(B)	LEFT SIDE PANEL	1	(D)	SUPPORT PANEL	1





Hardware List



SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT



CAM-LOCK



Quickfit head needs to be in centre


QUICKFIT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




5

STEP 1




STEP 2




AFTER SALES SUPPORT

 **NZ** 0800 422 274

STEP 3





STEP 4



7

STEP 5



AFTER SALES SUPPORT

 **NZ** 0800 422 274



**WORK
SPACE**

TM

Warranty

We pride ourselves on producing a range of quality products that are both packed with features and completely reliable. We are so confident in our products, we back them up with a 5 year warranty.

Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274

This Product is covered by 5 year warranty when accompanied by proof of purchase.

AFTER SALES SUPPORT

 **NZ** 0800 422 274