








Assembly Instructions
MODEL NO. :177519-1
 SLIDING DOOR CREDENZA-1200W

1	 Cam Lock 20pcs	2	 Klix Cam 20pcs	3	 Cam Cover 20pcs	4	 Dowel 20pcs	5	 CUSHION 25Hx-φ52 6pcs	6	 Screw 4*30mm 6pcs	7	 Shelf supporter 8 pcs	8	 Stainless Metal saddle strap 2cm	9	 Lock & Keys 1 set	10	 Screw 4*19mm 2pcs
---	---	---	--	---	---	---	---	---	---	---	---	---	---	---	---	---	---	----	---



- IMPORTANT NOTE:**
- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
 - Check to be sure that you have all parts and hardware.
 - Remove all wrapping materials, including staples & packing straps before you start to assemble.
 - Don't tighten all screws/bolts until all completely assembled.
 - Keep all hardware parts out of reach of children



IMPORTANT:

FUNCTION OF KLIX CAM

1/4 RIGHT TURN FOR LOCKING
 1/4 LEFT TURN FOR LOOKING

Make Sure The Arrow Is Pointing Upwards Before Inserting Into The Panel's Hole